



www.zyvex.com



The CNT Supply Chain from the Customer's Perspective

2nd Joint Workshop on Measurement Issues in
Single Wall Carbon Nanotubes: Purity & Dispersion

Mark Banash, PhD

January 26, 2005
NIST Gaithersburg, MD, USA




Our Vision

To be the leading worldwide supplier of tools, products, and services that enable adaptable, affordable, and molecularly precise manufacturing.



The Zyvex Approach: **NanoSolve™ Materials**

Core Competence: Functionalization



- **Two distinct functions:**
 - Non-damaging binding
 - Customizable
- **Binding applicable to CNTs (SWNTs, DWNTs, MWNTs)**
- **Functionality may be customized for different applications:**
 - Dispersion in solvents
 - Adhesion to composites
 - Other chemical functionality

**Kentera™
functionalization
technology**

- Capitalize on unique properties of carbon nanotube reinforcement for high performance composite materials
 - High strength
 - Low weight
 - High thermal conductivity
 - High electrical conductivity
 - High chemical and thermal stability




NanoSolve Polycarbonate






NanoSolve™ Dispersion

Product Comparison




Raw CNT product




Zyvex NanoSolve additive

Impurities in Raw CNT




Zyvex Date :27 Jun 2004 EHT = 2.00 kV MAG = 100.00 K X

300nm*



- Soft floc or sediment
- Could not be redispersed
- Elemental analysis confirms amorphous carbon or soot
- Several microns or greater in diameter
- Required additional filtering steps (\$)
- At \$500/g, this means \$100/g spent on waste
- Does not compete for dispersing agent

Impurities in Filtered CNT



Zyvex Date :27 Jun 2004 EHT = 2.00 kV MAG = 100.00 K X

200nm*




Foreign Matter in Dispersion

- X-ray analysis confirms metal particles (Fe)
- SEM shows them to be 200-300 nm in diameter
- CNTs adhering to trace catalyst material
- Cannot be filtered
- Cannot be exfoliated
- At \$500/g, this means \$50/g spent on waste

- **CNT content**
 - Must be at least 90%, preferably >95%
- **Amorphous carbon or soot**
 - Must be <10%, preferably <5%
 - Minimal filtering acceptable
- **Iron**
 - Must be <3%, preferably <1%
 - Each iron particle removes dozens of CNTs

Acceptable Raw CNTs



Zyvex Date :11 Dec 2003 EHT = 1.00 kV Mag = 50.00 K X

300nm

- **ASTM D1514**
 - Gravimetric (measures retained material)
 - Force material through 325 mesh with water spray
 - Measures soot in carbon black
 - Fast and cheap
 - Operationally acceptable

- **ASTM E394**
 - Measures iron spectrophotometrically
 - Fast, cheap, and accurate



Customers' Expectations

- **Property enhancement with CNTs**
 - Thermal
 - Electrical
 - Mechanical

- **Use of CNTs**
 - Little or no reformulation
 - Little or no process changes
 - Little or no capital costs
 - Product stable
 - Is made reproducibly
 - Qualities of interest measurable with established tolerances

What Makes a Nanotube Product?

- **Physical/Structural Properties of CNT**
 - Length
 - Diameter
 - Aspect ratio
 - Surface area
 - Fractal dimension
 - Defects
 - Chiral number
 - S/D/MWNT
- **Impurities**
 - Amorphous carbon
 - Trace metals
 - Trace inorganics



What Makes a Nanotube Product?

What is our customer's perspective?

- A real industrial process is variable
 - Probabilities replace determinism
 - Tolerances replace absolute values
- Exact cause-and-effect not possible
 - Too many processing variables
 - Too many component parts
 - Possible unknown interactions
- A consistent material described by a possibly incomplete set of factors is more valuable and practical than a variable material about which every factor is known



Consistency: A Customer's View

- There must be basic information about a CNT product
 - Composition
 - Purity
- The product must be supplied the same way each time
- The supplier must be able to scale production to meet demand without affecting quality
- The supplier has to be able to record, document, and explain how it does all of this to a customer



Customers' Interests in QA

- Clear, understandable measurement methods
- Metrics tied to the performance of our own products
- Applications to our own supply chain
 - Grade changes
 - Scalability
 - Product comparison
- Metrics are factors in their own formulation design



Purity, Quality, and CNTs

- A customer only needs enough information
- That information needs to be directly tied to a processing variable or concern
- Purity and quality standards for manufacturing can and will be less complete scientifically than for research applications
- Tests for purity and quality can be simple and straightforward
- No need for overquality



www.zyvex.com